

Bearbeitung	ISO-CODE	Position	Spantiefe	Ecken- radius	Wendeplatte P	Wendeplatte M	Wendeplatte K	Halten via
mittlere (S)	CCGT060202	neutral	0,5-2,0	0,2	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT060204	neutral	0,5-2,0	0,4	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT060208	neutral	0,5-2,0	0,8	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT09T302	neutral	0,5-2,0	0,2	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT09T304	neutral	0,5-2,0	0,4	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT09T308	neutral	0,5-2,0	0,8	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT120404	neutral	0,5-2,0	0,4	SHP895	SHP895	--	Schraube
mittlere (S)	CCGT120408	neutral	0,5-2,0	0,8	SHP895	SHP895	--	Schraube
schruppen (G)	CCMT060204	neutral	1,5-3,0	0,4	--	--	GHC820	Schraube
schruppen (G)	CCMT09T304	neutral	1,5-3,0	0,4	GHC865	--	GHC820	Schraube
schruppen (G)	CCMT09T308	neutral	1,5-3,0	0,8	GHC865	--	GHC820	Schraube
schruppen (G)	CCMT120408	neutral	1,5-3,0	0,8	GHC865	--	GHC820	Schraube
schruppen (G)	CCMT120412	neutral	1,5-3,0	1,2	GHC865	--	GHC820	Schraube
mittlere (S)	CCMT060202	neutral	0,5-2,0	0,2	--	--	SHC820	Schraube
mittlere (S)	CCMT060204	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC820	Schraube
mittlere (S)	CCMT060208	neutral	0,5-2,0	0,8	SHP895	SHP895	SHC820	Schraube
mittlere (S)	CCMT09T302	neutral	0,5-2,0	0,2	SHC850	--	SHC820	Schraube
mittlere (S)	CCMT09T304	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC820	Schraube
mittlere (S)	CCMT09T308	neutral	0,5-2,0	0,8	SHP895	SHP895	SHC820	Schraube
mittlere (S)	CCMT120404	neutral	0,5-2,0	0,4	SHC850	--	SHC820	Schraube
mittlere (S)	CCMT120408	neutral	0,5-2,0	0,8	SHP865	SHC875	SHC820	Schraube
mittlere (S)	CCMT120412	neutral	0,5-2,0	1,2	SHP865	--	SHC820	Schraube
schlichten (F)	CCMT060202	neutral	0,5-2,0	0,2	FHP895	FHP895	--	Schraube
schlichten (F)	CCMT060204	neutral	0,5-2,0	0,4	FHP895	FHP895	FHC820	Schraube
schlichten (F)	CCMT060208	neutral	0,5-2,0	0,8	FHP895	FHP895	FHC820	Schraube
schlichten (F)	CCMT09T302	neutral	0,5-2,0	0,2	FHP895	FHP895	--	Schraube

schlichten (F)	CCMT09T304	neutral	0,5-2,0	0,4	FHP895	FHP895	FHC820	Schraube
schlichten (F)	CCMT09T308	neutral	0,5-2,0	0,8	FHP895	FHP895	FHC820	Schraube
schruppen (G)	DCMT11T304	neutral	1,5-3,0	0,4	GHC865	--	GHC815	Schraube
schruppen (G)	DCMT11T308	neutral	1,5-3,0	0,8	GHC865	--	GHC815	Schraube
mittlere (S)	DCMT070202	neutral	0,5-2,0	0,2	--	--	SHC815	Schraube
mittlere (S)	DCMT070204	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC815	Schraube
mittlere (S)	DCMT070208	neutral	0,5-2,0	0,8	SHC865	--	SHC815	Schraube
mittlere (S)	DCMT11T302	neutral	0,5-2,0	0,2	SHC850	--	SHC815	Schraube
mittlere (S)	DCMT11T304	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC815	Schraube
mittlere (S)	DCMT11T308	neutral	0,5-2,0	0,8	SHP895	SHP895	SHC815	Schraube
mittlere (S)	DCMT150404	neutral	0,5-2,0	0,4	--	--	SHC815	Schraube
mittlere (S)	DCMT150408	neutral	0,5-2,0	0,8	--	--	SHC815	Schraube
mittlere (S)	DCMT150412	neutral	0,5-2,0	1,2	--	--	SHC815	Schraube
schlichten (F)	DCMT070202	neutral	0,5-2,0	0,2	FHP895	FHP895	--	Schraube
schlichten (F)	DCMT070204	neutral	0,5-2,0	0,4	FHP895	FHP895	--	Schraube
schlichten (F)	DCMT11T302	neutral	0,5-2,0	0,2	FHP895	FHP895	--	Schraube
schlichten (F)	DCMT11T304	neutral	0,5-2,0	0,4	FHP895	FHP895	FHC815	Schraube
schlichten (F)	DCMT11T308	neutral	0,5-2,0	0,8	FHP895	FHP895	--	Schraube
schruppen (G)	SCMT09T308	neutral	1,5-3,0	0,8	GHC865	--	GHC820	Schraube
schruppen (G)	SCMT120408	neutral	1,5-3,0	0,8	GHC865	--	GHC820	Schraube
schruppen (G)	SCMT120412	neutral	1,5-5,0	1,2	--	--	GHC820	Schraube
mittlere (S)	SPMT060304	neutral	0,5-2,0	0,4	SHC865	--	SHC820	Schraube
mittlere (S)	SPMT060308	neutral	0,5-2,0	0,8	--	--	SHC820	Schraube
mittlere (S)	SCMT09T304	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC820	Schraube
mittlere (S)	SCMT09T308	neutral	0,5-2,0	0,8	SHC865	SHC875	SHC820	Schraube
mittlere (S)	SCMT120404	neutral	0,5-2,0	0,4	--	--	SHC820	Schraube
mittlere (S)	SCMT120408	neutral	0,5-2,0	0,8	SHC865	SHC875	SHC820	Schraube
schlichten (F)	SPMT060304	neutral	0,5-2,0	0,4	FHC865	FHP895	FHC820	Schraube
schlichten (F)	SCMT09T304	neutral	0,5-2,0	0,4	FHP895	FHP895	FHC820	Schraube

schlichten (F)	SCMT09T309	neutral	0,5-2,0	0,8	FHP895	FHP895	FHC820	Schraube
schruppen (G)	TCMT110204	neutral	1,5-3,0	0,4	GHC865	--	--	Schraube
schruppen (G)	TCMT110204	neutral	1,5-4,0	0,4	--	--	GHC815	Schraube
schruppen (G)	TCMT16T304	neutral	1,5-3,0	0,4	GHC865	--	--	Schraube
schruppen (G)	TCMT16T304	neutral	1,5-4,0	0,4	--	--	GHC815	Schraube
schruppen (G)	TCMT16T308	neutral	1,5-3,0	0,8	GHC865	--	--	Schraube
schruppen (G)	TCMT16T308	neutral	1,5-5,0	0,8	--	--	GHC815	Schraube
mittlere (S)	TCMT090204	neutral	0,5-2,0	0,4	SHC850	--	SHC815	Schraube
mittlere (S)	TCMT110204	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC815	Schraube
mittlere (S)	TCMT110208	neutral	0,5-2,0	0,8	SHP895	SHP895	SHC815	Schraube
mittlere (S)	TCMT16T304	neutral	0,5-2,0	0,4	SHP895	SHP895	SHC815	Schraube
mittlere (S)	TCMT16T308	neutral	0,5-2,0	0,8	SHP895	SHP895	SHC815	Schraube
mittlere (S)	TCMT16T312	neutral	0,5-2,0	1,2	SHC865	--	SHC815	Schraube
mittlere (S)	TCMT220408	neutral	0,5-2,0	0,8	--	--	SHC815	Schraube
schlichten (F)	TCMT110202	neutral	0,5-2,0	0,2	SHP895	FHP895	--	Schraube
schlichten (F)	TCMT110204	neutral	0,5-2,0	0,4	SHP895	FHP895	FHC815	Schraube
schlichten (F)	TCMT16T304	neutral	0,5-2,0	0,4	SHP895	FHP895	--	Schraube
schlichten (F)	TCMT16T308	neutral	0,5-2,0	0,8	SHP895	FHP895	--	Schraube
mittlere (S)	VCGT110304	neutral	0,5-2,0	0,4	SHP880	SHP880	--	Schraube
schruppen (G)	VCMT160408	neutral	1,5-3,0	0,8	GHC865	--	--	Schraube
mittlere (S)	VCMT160404	neutral	0,5-2,0	0,4	SHC865	--	SHC815	Schraube
mittlere (S)	VCMT160408	neutral	0,5-2,0	0,8	SHC865	--	SHC815	Schraube